

# **OCT Engine Communications Command Specification**

Copyright (C) 2018, Axsun Technologies, Inc.

ALL RIGHTS RESERVED

NO PART OF THIS DOCUMENT MAY BE REPRODUCED IN ANY FORM  
WITHOUT THE EXPRESS WRITTEN PERMISSION OF  
AXSUN TECHNOLOGIES, INC  
ONE FORTUNE DRIVE – BILLERICA, MA 01821  
USA

# OCT Control Interface Specification

## Axsun OCT Control Interface

OCT Engine Communications Command Specification .....	1
Axsun OCT Control Interface.....	3
1. Introduction.....	5
2. Communication Protocol .....	5
3. Events.....	5
OCTDeviceConnectedEvent.....	5
OCTDeviceDisconnectedEvent .....	5
4. Fields (Numerical Defines).....	6
USB Error Codes .....	6
5. Fields (Numerical Defines).....	6
CommandIDs .....	6
USB Error Codes .....	7
6. Generic Methods.....	7
bool CheckIfOCTDevicePresent().....	7
string GetControlBuildDate() .....	7
string GetControlName() .....	8
string GetControlVersion() .....	8
string GetErrorString().....	8
void Initialize().....	8
void GetLastCommandInfo().....	8
UInt32 RebootSystem() .....	8
UInt32 GetFirmwareVersion().....	8
UInt32 GetFirmwareBuildDate().....	9
UInt32 GetSystemType().....	9
UInt32 GetSerialNum() .....	9
Bool IsOCTDeviceConnected ().....	9
Int GetNumberOfOCTDevicesPresent ().....	9
Bool ConnectToOCTDevice ().....	10
UInt32 GetBootErrors() .....	10
UInt32 GetUSBInfo() .....	10
UInt32 GetPartNum() .....	10
UInt32 GetManufacturer() .....	11
UInt32 GetNumericalFirmwareVersion().....	11
7. Engine Specific Methods .....	11
UInt32 StartScan() .....	11
UInt32 StopScan() .....	11
UInt32 GetSystemStatus() .....	11
UInt32 GetTECStatus() .....	12
UInt32 ResetTEC() .....	13
UInt32 GetLowSpeedADData() .....	13
UInt32 SwitchConfiguration() .....	14
UInt32 GetConfiguration () .....	14
UInt32 GetLoadedConfiguration() .....	14
UInt32 GetSystemErrorStates() .....	14
UInt32 ResetSystemErrorState() .....	15
UInt32 SourceCurrentOn() .....	15

## OCT Control Interface Specification

UInt32 SourceCurrentOff().....	15
UInt32 GetLaserOnTime().....	15
UInt32 GetSystemOnTime().....	16
UInt32 GetWavelengthAtSweepTrigger().....	16
UInt32 GetWavelengthAtEndTrigger().....	16
UInt32 GetKClockFSR ().....	16
UInt32 HomeVDL ().....	16
UInt32 MoveRelVDL ().....	17
UInt32 MoveAbsVDL ().....	17
8. DAQ Specific Methods.....	17
UInt32 SetFPGARegister ().....	17
UInt32 GetFPGARegister().....	17
UInt32 SetFPGASettings().....	18
UInt32 GetFPGASettings().....	18
UInt32 SendFPGAData().....	18
UInt32 WriteDAQRegisterBit ().....	18
9. Cameralink ADC Specific Methods.....	19
UInt32 SetFPGASettings().....	19
UInt32 GetFPGASettings().....	19
UInt32 FPGAADCEnable().....	19
10. Example C# Code.....	20
11. Error Codes.....	21

## 1. Introduction

This document describes the interface of the Axsun OCT control. The Axsun OCT control is a windows C# control used for communication to the Axsun OCT engine. It is in the form of a single .dll called AxsunOCTControl.dll. It needs no other controls to be installed in the system besides the Microsoft .NET framework. It communicates to the OCT device over USB.

## 2. Communication Protocol

The Axsun OCT control has several public methods to communicate as well as events to notify the host program that the OCT USB device has either connected or disconnected.

The OCT device will only send back data in response to a command.

## 3. Events

The OCT control has windows events to signal when the device is connected or disconnected. These events may or may not be used to communicate with the OCT device

### OCTDeviceConnectedEvent

The OCTDeviceConnectedEvent Event is called when a device is plugged into the USB or is powered on.

The event is set up to be called from a C# program like this:

```
// Create New OCT Control
AOCT = new AxsunOCTControl.AxsunOCTControl();

// Call Initialize to look for OCT USB driver and check if there is a
// device attached
AOCT.Initialize();

// Connect up the OCTDeviceConnectedEvent to a function we have locally
// called AOCT_OCTDeviceConnectedEvent
AOCT.OCTDeviceConnectedEvent += new
AxsunOCTControl.AxsunOCTControl.OCTDeviceConnectedHandler(AOCT_OCTDeviceConnectedEvent);

// Now that the event is connected, every time an OCT device is plugged
// in, the following function will be called.
// In the OCT host program, this function queries and displays the
// firmware version in the status bar

void AOCT_OCTDeviceConnectedEvent()
{
    ...
}
```

### OCTDeviceDisconnectedEvent

The OCTDeviceDisconnectedEvent is called whenever a USB device is disconnected from the system. Usage of this event is similar to the OCTDeviceConnectedEvent above. The line to add the event handler in C# is:

## OCT Control Interface Specification

```
AOCT.OCTDeviceDisconnectedEvent += new  
AxsunOCTControl.AxsunOCTControl.OCTDeviceDisconnectedHandler(AOCT_OCTDeviceDisconnectedEv  
ent);
```

### 4. Fields (Numerical Defines)

The OCT control makes public a list of numerical defines for use when programming.

#### USB Error Codes

The USBErrorCodes list has a list of error codes returned from the OCT control that deal with USB communication errors. There is no list of error codes for the device itself. If there is an error on the OCT device an error code will be returned that is less than 1000. The calling program can then query the OCT device for the string that defines that error code by calling `GetErrorString(UInt32 ErrorCode)`.

For any errors that involve USB communications, however, querying the device is probably not possible and so the list of errors are provided here.

```
public const int ERROR_READING = 1000;  
public const int ERROR_WRITING = 1001;  
public const int NO_DEVICE_PRESENT = 1002;  
public const int CHECKSUM_ERROR = 1003;  
public const int TOO_MANY_PACKET_TRIES = 1004;
```

### 5. Fields (Numerical Defines)

The OCT control makes public a list of numerical defines for use when programming.

#### CommandIDs

The CommandID list has defines for all the commands used by the OCT device.

```
public const UInt32 GET_FW_VERSION = 100;  
public const UInt32 LOAD_DAC = 101;  
public const UInt32 RETURN_DAC = 102;  
public const UInt32 START_SWEEP = 103;  
public const UInt32 END_SWEEP = 104;  
public const UInt32 LOAD_FIRMWARE = 105;  
public const UInt32 GET_BUILD_DATE = 106;  
public const UInt32 LOAD_SCAN_SETTINGS = 107;  
public const UInt32 GET_SCAN_SETTINGS = 108;  
public const UInt32 GET_ERROR_STRING = 109;  
public const UInt32 GET_LOW_SPEED_AD = 110;  
public const UInt32 WRITE_TO_DIAGNOSTIC = 111;  
public const UInt32 GET_DIAGNOSTIC = 112;  
public const UInt32 GET_USB_DATA = 113;  
public const UInt32 SET_TIMER_ENABLE = 114;  
public const UInt32 GET_TEC_STATE = 115;  
public const UInt32 RESET_TEC = 116;  
public const UInt32 SET_SERIAL_NUM = 117;  
public const UInt32 GET_SERIAL_NUM = 118;  
public const UInt32 PARK_FILTER = 119;  
public const UInt32 GET_BOOT_ERRORS = 120;  
public const UInt32 GET_SYSTEM_STATUS = 121;
```

## OCT Control Interface Specification

```
public const UInt32 SW_RESET = 122;
public const UInt32 GET_SYSTEM_TYPE = 123;
public const UInt32 SET_LOW_SPEED_AD_POLLING = 124;
public const UInt32 ARE_OTHER_BOARDS_ATTACHED = 125;
public const UInt32 GET_NUMERICAL_FV_VERSION = 126;
public const UInt32 GET_DEBUG_TEXT = 127;
public const UInt32 CLEAR_DEBUG_TEXT = 128;
public const UInt32 GET_PIM_SETTINGS = 131;
public const UInt32 SET_PIM_SETTINGS = 132;

public const UInt32 LOAD_FPGA = 201;
public const UInt32 RESET_FPGA = 202;
public const UInt32 GET_FPGA_SETTINGS = 203;
public const UInt32 SET_FPGA_SETTINGS = 204;
public const UInt32 GET_FPGA_IMAGE = 205;
public const UInt32 JUST_PROGRAM_FPGA = 206;
public const UInt32 GET_FPGA_REGISTERS = 207;
public const UInt32 SET_FPGA_REGISTER = 208;
public const UInt32 FPGA_ADC_ENABLE = 209;
public const UInt32 LOAD_FPGA_MULTISECTION = 210;
public const UInt32 HEARTBEAT = 300;
public const UInt32 HOME_VDL = 301;
public const UInt32 MOVE_ABS_VDL = 302;
public const UInt32 MOVE_REL_VDL = 303;
public const UInt32 GET_VDL_STATUS = 304;
```

### USB Error Codes

The USBErrorCodes list has a list of error codes returned from the OCT control that deal with USB communication errors. There is no list of error codes for the device itself. If there is an error on the OCT device an error code will be returned that is less than 1000. The calling program can then query the OCT device for the string that defines that error code by calling `GetErrorString(UInt32 ErrorCode)`.

For any errors that involve USB communications, however, querying the device is probably not possible and so the list of errors are provided here.

```
public const int ERROR_READING = 1000;
public const int ERROR_WRITING = 1001;
public const int NO_DEVICE_PRESENT = 1002;
public const int CHECKSUM_ERROR = 1003;
public const int TOO_MANY_PACKET_TRIES = 1004;
```

### 6. Generic Methods

These are commands than are available for use on all OCT devices.

#### **bool** CheckIfOCTDevicePresent()

This function is obsolete. It is included for backward compatibility. Use `IsOCTDeviceConnected()` instead.

#### **string** GetControlBuildDate()

Returns a string with the build date of the OCT control. This function does not communicate with the OCT device and the OCT device does not need to be connected for this function to return its value.

**string GetControlName()**

Returns the product name of the control.

**string GetControlVersion()**

Returns the version of just the OCT control, not the firmware version.

**string GetErrorString()**

Returns a string to describe the error matching the ErrorCode value. Error numbers and description strings are only stored onboard the OCT device. This was designed so that changes can be made to just the OCT device firmware including adding error codes without needing to change the host program or OCT control program. \

Parameters:

UInt32	Error Code	
--------	------------	--

**void Initialize()**

Obsolete. This command has no functionality. Included for backward compatibility.

**void GetLastCommandInfo()**

Returns diagnostic information about the last command sent to the host

Parameters:

ref int	BytesSent	
ref int	PacketsSent	
ref int	PacketsRetried	
ref int	Timeouts	
ref int	ChecksumErrors	
ref int	TimeTaken	
ref int	DataBytes	

**UInt32 RebootSystem()**

Reboots the OCT. Useful after a firmware download. No Parameters are passed.

Returns an error code or 0 if there was no error.

**UInt32 GetFirmwareVersion()**

Returns a string containing the firmware version and the CPU version.

Parameters:

Ref String	Firmware Version String	
------------	-------------------------	--

Returns an error code or 0 if there was no error.

**UInt32 GetFirmwareBuildDate()**

Returns the build date of the firmware.

Parameters:

<a href="#">Ref String</a>	Firmware Build Date	
----------------------------	---------------------	--

Returns an error code or 0 if there was no error.

**UInt32 GetSystemType()**

Gets the type of the currently connected board.

Type definitions are exposed in the enum OCT\_SYSTEM\_TYPES:

```
public const UInt32 SYSTEM_TYPE_NOT_CONNECTED = 0;
public const UInt32 SYSTEM_TYPE_OCT_LASER = 40;
public const UInt32 SYSTEM_TYPE_OCT_CAMERALINK = 41;
public const UInt32 SYSTEM_TYPE_OCT_PIM = 42;
```

Parameters:

<a href="#">Ref UInt32</a>	SystemType	Number indicating system type
<a href="#">Ref string</a>	SystemTypeString	String containing the system type

Returns an error code or 0 if there was no error

**UInt32 GetSerialNum()**

Gets the current serial number.

Parameters:

<a href="#">Ref String</a>	Serial Number	Serial Number of up to 40 characters
----------------------------	---------------	--------------------------------------

Returns an error code or 0 if there was no error.

**Bool IsOCTDeviceConnected ()**

Checks if a device is connected.

Returns true if connected, false if not.

**Int GetNumberOfOCTDevicesPresent ()**

Returns the number of OCT devices that are connected to the system. (Plugged in and powered on)

### Bool ConnectToOCTDevice ()

Connects to a specific OCT device. Number must be between 0 and the number returned from GetNumberOfOCTDevicesPresent() above.

Parameters:

int	DeviceNum	
-----	-----------	--

Returns an error code or 0 if there was no error.

### UInt32 GetBootErrors()

Gets a list of any errors that occurred during system startup

Parameters:

Ref UInt32[]	Boot Errors	Array of errors. Array size must be at least 50.
Ref UInt32	Num Boot Errors	Number of boot errors that occurred

Returns an error code or 0 if there was no error.

### UInt32 GetUSBInfo()

Gets an array containing USB Information.

Parameters:

Ref UInt32[]	Status Array of size 5	PacketsRead - number of packets since power on ChecksumErrors - number of checksum errors since power on PacketErrors - number of packet errors since power on TimeoutErrors- number of timeout errors since power on CommandsReceived - number of commands received since power on ConnectCount - number of connections made since power on
Ref UInt32	Words Returned	Size of USB status array

Returns an error code or 0 if there was no error.

### UInt32 GetPartNum()

Gets the current part number.

Parameters:

<a href="#">Ref String</a>	Serial Number	Serial Number of up to 40 characters
----------------------------	---------------	--------------------------------------

Returns an error code or 0 if there was no error.

### **UInt32 GetManufacturer()**

Gets the manufacturer. Always returns “Axsun”.

Parameters:

<a href="#">Ref String</a>	Serial Number	String containing “Axsun”
----------------------------	---------------	---------------------------

Returns an error code or 0 if there was no error.

### **UInt32 GetNumericalFirmwareVersion()**

Gets the firmware version as a set of integers. If the version is “V 1.17.15” then V1 = 1, V2 = 17 and V3 = 15.

Parameters:

<a href="#">Ref UInt32</a>	V1	First version digit
<a href="#">Ref UInt32</a>	V2	Second version digit
<a href="#">Ref UInt32</a>	V3	Third version digit

Returns an error code or 0 if there was no error.

## **7. Engine Specific Methods**

These are commands that are available only on OCT laser engines.

### **UInt32 StartScan()**

Start the OCT Engine Scanning. No Parameters are passed.

Returns an error code or 0 if there was no error.

### **UInt32 StopScan()**

Stops the OCT Engine Scanning. No Parameters are passed.

Returns an error code or 0 if there was no error.

### **UInt32 GetSystemStatus()**

Gets an array containing system Status.

## OCT Control Interface Specification

Parameters:

<a href="#">Ref UInt32[]</a>	Status Array of size 20	Uptime - ms system has been powered on Sweeping - 1 = sweeping, 0 = not sweeping DMAError - a DMA error has occurred PPIError - a PPI error has occurred TECError - a TEC error has occurred PPIErrors - number of PPI errors since power on Boot Reg 1 – Reason for last Reboot Boot Reg 2– Reason for last Reboot
<a href="#">Ref UInt32</a>	Status Words	Size of status array

Returns an error code or 0 if there was no error.

### **UInt32 GetTECStatus()**

Gets debug information about the TEC. The most current information is returned in the data fields. History data for the last 50 seconds is also returned in the data field.

If a TEC error occurs the TEC is turned off and history data stops collecting.

Parameters:

<a href="#">Ref UInt32</a>	TEC State	Current TEC State 0 TEC_UNINT 1 TEC_WARMING_UP 2 TEC_WAITING_IN_RANGE 3 TEC_READY 4 TEC_OFF_ERROR
<a href="#">Ref UInt32</a>	Counts in range	Number of seconds that the TEC has been in range
<a href="#">Ref UInt32</a>	Counts Warming up	Number of seconds the TEC has been warming up for.
<a href="#">Ref UInt32</a>	Counts out of range	Number of seconds the TEC has been out of range after coming in range.
<a href="#">Ref UInt32</a>	TEC Error	If the TEC was shut down, the reason it was shut down. 16 TEC_NEVER_GOT_TO_READY 17 TEC_WENT_OUT_OF_RANGE The string for this error code can be returned by using the GetErrorString command (109)
<a href="#">Ref int</a>	TEC Temp	Current temperature. This temperature is the float temperature multiplied by 100 and returned as an integer. So, a temperature of 24.174 will be returned as an integer 2417.
<a href="#">Ref UInt32</a>	Points Returned	The number of data points returned in the following 3 arrays. Right now the system

## OCT Control Interface Specification

		returns 50.
<a href="#">Ref int[]</a>	TEC Temps	Temperature as an integer of the temperature multiplied by 100.
<a href="#">Ref UInt32[]</a>	TEC Times	Time in milliseconds as a 32 bit integer
<a href="#">Ref UInt32[]</a>	TEC States	TEC state as a 32 bit integer.

Returns an error code or 0 if there was no error.

### **UInt32 ResetTEC()**

Resets the TEC. Turns the TEC off, sets the temperature with a D-A write, turns it on, and resets any error code and all the TEC counters. No Parameters are passed.

Returns an error code or 0 if there was no error.

### **UInt32 GetLowSpeedADData()**

Returns the 16 channels of low speed A→D data. The data is returned as 3 arrays of data.

Parameters:

<a href="#">Ref UInt32[]</a>	RawVals	Raw integer data in 16 bit integers
<a href="#">Ref Single[]</a>	ScaledVals	Converted values in 32 bit floats
<a href="#">Ref String[]</a>	FieldNames	Strings to label each channel
<a href="#">Ref UInt32</a>	ChannelsReturned	Number of channels of data returned

Using this technique, the firmware can add or delete A→D channels without needing new host software.

Currently, the channels returned are:

0	Reference Monitor
1	Signal Monitor
2	Pointer laser current
3	Filter Voltage
4	Laser Current
5	Laser TEC thermistor
6	Laser TEC current
7	Laser TEC voltage
8	Board temperature
9	Ground
10	Spare
11	3.3V reference
12	-5V
13	+5V
14	15V
15	150V

Returns an error code or 0 if there was no error.

### UInt32 SwitchConfiguration()

Switches the DAC table to another configuration. Configuration numbers are numbered from 0 to the number of loaded configurations - 1. If 3 configurations are loaded, valid values are from 0 to 2. If a configuration is selected that is not yet set up, the error CONFIGURATION\_NOT\_SETUP (140) will be returned.

Parameters:

int	ConfigNumber	Different configuration to switch to.
-----	--------------	---------------------------------------

Returns an error code or 0 if there was no error.

### UInt32 GetConfiguration ()

Returns the number of the current DAC table configuration. Configuration numbers are numbered from 0 to the number of loaded configurations - 1.

Parameters:

Ref int	ConfigNumber	Which configuration is currently active.
---------	--------------	--

Returns an error code or 0 if there was no error.

### UInt32 GetLoadedConfiguration()

Returns the number of DAC table configurations that have been loaded into this device. This number can range from 1 to the number of loaded configurations.

Parameters:

Ref int	LoadedConfigurations	The number of configurations that have been loaded to this device.
---------	----------------------	--

Returns an error code or 0 if there was no error.

### UInt32 GetSystemErrorStates()

Returns a class containing error states for individual voltages and TECs as well as an overall "System is in Error" state that is active whenever there is at least 1 error. Individual error states are booleans (True = error on that channel, false = no error on that channel)

Parameters:

Ref SystemErrorStateType	SystemErrorStates	Class containing Booleans for each individual system error state as defined below.
--------------------------	-------------------	--

```
class SystemErrorStateType
{
    bool SystemIsInError;           Overall Error State
```

## OCT Control Interface Specification

```
bool BPowerMonitorInError;    Power Monitor Channel
bool B33RefInError;          3.3V Reference Channel
bool BMinus5VInError;        -5V Channel
bool B5VInError;             5V Channel
bool B15VInError;            15V Channel
bool B180VInError;           180V Channel
bool TEC0Error;              TEC 1 Channel
bool TEC1Error;              TEC 2 Channel
bool BoardTempError;         Board Temperature
}
```

Returns an error code or 0 if there was no error.

### **UInt32 ResetSystemErrorState()**

This will reset any error state including a TEC error. If a TEC is in an error state it will be re-started as if it was powered on.

Parameters:  
None

Returns an error code or 0 if there was no error.

### **UInt32 SourceCurrentOn()**

Turns on the light source current.

Parameters:  
None

Returns an error code or 0 if there was no error.

### **UInt32 SourceCurrentOff()**

Turns on the light source current.

Parameters:  
None

Returns an error code or 0 if there was no error.

### **UInt32 GetLaserOnTime()**

Returns the number of seconds that the laser has been in use for the lifetime of the laser on this system.

Parameters:

Ref UInt32	LaserOnTimeSeconds	Number of seconds that the laser has been on.
------------	--------------------	---

Returns an error code or 0 if there was no error.

**UInt32 GetSystemOnTime()**

Returns the number of seconds that the system has been powered on for the lifetime of this device.

Parameters:

Ref UInt32	SystemOnTimeSeconds	Number of seconds that the device has been powered on.
------------	---------------------	--

Returns an error code or 0 if there was no error.

**UInt32 GetWavelengthAtSweepTrigger()**

Returns the wavelength at the sweep trigger for this system in nm. If multiple DAC tables are loaded, this will return the wavelength at the sweep trigger for the currently selected DAC table.

Parameters:

Ref double	Wavelength	Wavelength at sweep trigger in nm for this system
------------	------------	---

Returns an error code or 0 if there was no error.

**UInt32 GetWavelengthAtEndTrigger()**

Returns the wavelength at the end trigger for this system in nm.

Parameters:

Ref double	Wavelength	Wavelength at end trigger in nm for this system
------------	------------	---

Returns an error code or 0 if there was no error.

**UInt32 GetKClockFSR ()**

Returns the KClock Free Spectral Range for this system in GHz.

Parameters:

Ref double	Free Spectral Range	KClock FSR for this system in GHz
------------	---------------------	-----------------------------------

Returns an error code or 0 if there was no error.

**UInt32 HomeVDL ()**

Sends the VDL motor to its home position

Parameters:

None

Returns an error code or 0 if there was no error.

### **UInt32 MoveRelVDL ()**

Moves the VDL to a relative position at a specific speed. Positive values will move the VDL forward away from home negative values will move the VDL backward.

Parameters:

<a href="#">Single</a>	Position	Relative amount to move in mm
<a href="#">Single</a>	Speed	Speed to move at in mm/sec

Returns an error code or 0 if there was no error.

### **UInt32 MoveAbsVDL ()**

Moves the VDL to an absolute position at a specific speed. Position needs to be a positive number of millimeters away from home.

Parameters:

<a href="#">Single</a>	Position	Absolute amount to move in mm
<a href="#">Single</a>	Speed	Speed to move at in mm/sec

Returns an error code or 0 if there was no error.

## **8. DAQ Specific Methods**

### **UInt32 SetFPGARegister ()**

Sets one FPGA register

Parameters:

<a href="#">UInt32</a>	RegNum	Register number
<a href="#">UInt32</a>	RegVal	Value to set register to

Returns an error code or 0 if there was no error.

### **UInt32 GetFPGARegister()**

Gets a value for a single FPGA Register

Parameters:

<a href="#">UInt32[]</a>	Regnum	Register number
<a href="#">Ref UInt16</a>	Regval	Returned register value

### **UInt32 SetFPGASettings()**

Sends FPGA settings to device. These settings are an array of integers and are stored in flash. They are written to the FPGA after FPGA configuration.

Parameters:

<a href="#">UInt32</a>	NumIntScanSettings	Number of scan settings to write
<a href="#">Int[]</a>	IntScanSettings	Array of integers

Returns an error code or 0 if there was no error.

### **UInt32 GetFPGASettings()**

Returns FPGA settings from a device.

Parameters:

<a href="#">Ref UInt32</a>	NumIntScanSettings	Number of scan settings returned
<a href="#">Ref Int[]</a>	IntScanSettings	Array of integers
<a href="#">Ref string[]</a>	IntScanSettingNames	Strings containing descriptions of each scan setting

### **UInt32 SendFPGAData()**

Send a block of data to the DAQ FPGA.

Parameters:

<a href="#">UInt16</a>	FPGAData	Data array to send
<a href="#">Int</a>	nWords	Number of integers in data array
<a href="#">UInt32</a>	Location	FPGA register to load the data into
<a href="#">UInt32</a>	StartAddr	Starting FPGA address to write to

Returns an error code or 0 if there was no error.

### **UInt32 WriteDAQRegisterBit ()**

Changes 1 bit in an FPGA register

Parameters:

UInt32	RegisterNumber	Register Number
UInt32	Bit	Which bit to change (0-16)
UInt32	Value	Bit value (0 or 1)

Returns an error code or 0 if there was no error.

## 9. Cameralink ADC Specific Methods

### UInt32 SetFPGASettings()

Sends FPGA settings to the Cameralink ADC device and writes them to flash

Parameters:

UInt32	NumIntScanSettings	Number of FPGA settings to write
Int[]	IntScanSettings	Array of integers to be stored as FPGA settings

Returns an error code or 0 if there was no error.

### UInt32 GetFPGASettings()

Gets FPGA settings from the Cameralink ADC device

Parameters:

Ref UInt32	NumIntScanSettings	Number of FPGA settings to write
Ref Int[]	IntScanSettings	Array of integers to be stored as FPGA settings
Ref string[]	IntScanSettingNames	Array of strings containing the names of the scan settings

Returns an error code or 0 if there was no error.

### UInt32 FPGAADCEnable()

Turns on or off the A→D converter on Cameralink ADC

Parameters:

Bool	Enable	Boolean to turn ADC on or off
------	--------	-------------------------------

Returns an error code or 0 if there was no error.

## 10. Example C# Code

The following code demonstrates how to use the OCT Control to connect up the **device connected** event, connect to a device, request the firmware version and get a description of any error that is returned.

```
public class Form1 : Form
{
    public AxsunOCTControl.AxsunOCTControl AOCT;
    bool OCTConnected = false;

    public Form1()
    {
        InitializeComponent();

        AOCT = new AxsunOCTControl.AxsunOCTControl();

        // The next line wires up the device connected event.
        AOCT.OCTDeviceConnectOrDisconnectEvent += new
AxsunOCTControl.AxsunOCTControl.OCTDeviceConnectOrDisconnectHandler(AOCT_OCTDeviceConnect
OrDisconnectEvent);

        this.Controls.Add(AOCT);
        ConnectToFirstDevice();

        if (OCTConnected)
        {
            Label1.Text = "OCT Connected";
            label2.Text = GetFirmwareVersion(false);
        }
    }

    // Connects to the first enumerated OCT device.
    // This may be modified to connect to another device
    // by changing the value in ConnectToOCTDevice().
    void ConnectToFirstDevice()
    {
        bool result;

        if (AOCT.GetNumberOfOCTDevicesPresent() > 0)
        {
            result = AOCT.ConnectToOCTDevice(0);
            if (result)
            {
                OCTConnected = true;
            }
            else
            {
                OCTConnected = false;
            }
        }
        else
        {
            OCTConnected = false;
        }
    }

    // Gets the firmware version from the OCT device
    public string GetFirmwareVersion()

```

## OCT Control Interface Specification

```
{
    UInt32 result;
    string FirmwareVersion = "";

    result = AOCT.GetFirmwareVersion(ref FirmwareVersion);
    ShowOCTError(result);
    return FirmwareVersion;
}

// Displays a message box with the string to match the
// numeric error code
private void ShowOCTError(UInt32 ErrorVal)
{
    string ErrorString;

    if (ErrorVal != 0)
    {
        ErrorString = AOCT.GetErrorString(ErrorVal);
        MessageBox.Show(ErrorString + " (" + ErrorVal.ToString() + ")",
Application.ProductName);
    }
}

// This event is called whenever a device is either
// plugged in or unplugged.
void AOCT_OCTDeviceConnectOrDisconnectEvent()
{
    ConnectToFirstDevice();
}
}
```

### 11. Error Codes

Below is a reference list of all error codes. Alternatively, GetErrorString() can be called to return the string for the error.

#### Firmware Error Codes:

OK	= 0,
USB_CHECKSUM_ERROR	= 1,
USB_TIMEOUT_ERROR	= 2,
USB_READ_ERROR	= 3,
USB_WRITE_ERROR	= 4,
HIGHEST_USB_ERROR	= 5,
DAC_TABLE_TOO_LARGE	= 6,
SCAN_SETTING_COUNT_MISMATCH	= 7,
INVALID_SCAN_SETTINGS	= 8,
INVALID_ERROR_CODE	= 9,
INVALID_DA_CHANNEL	= 10,
INVALID_DIAGNOSTIC_TYPE	= 11,
INVALID_DIAGNOSTIC_IO	= 12,
INVALID_CLOCK_DELAY	= 13,
INVALID_COMMAND	= 14,
INVALID_CHANNEL	= 15,
TEC_NEVER_GOT_TO_READY	= 16,
TEC_WENT_OUT_OF_RANGE	= 17,
FLASH_ERR_POLL_TIMEOUT	= 18, // Polling toggle bit failed
FLASH_ERR_VERIFY_WRITE	= 19, // Verifying write to flash failed

## OCT Control Interface Specification

FLASH_ERR_INVALID_SECTOR	= 20, // Invalid Sector
FLASH_ERR_INVALID_BLOCK	= 21, // Invalid Block
FLASH_UNKNOWN_COMMAND	= 22, // Unknown Command
FLASH_ERR_PROCESS_COMMAND	= 23, // Processing command
FLASH_NOT_READ_ERROR	= 24, // Could not read memory from target
FLASH_DRV_NOTAT_BREAK	= 25, // The drive was not at AFP_BreakReady
FLASH_BUFFER_IS_NULL	= 26, // Could not allocate storage for the buffer
FLASH_NO_ACCESS_SECTOR	= 27, // Cannot access the sector( could be locked or something is stored there that should not be touched )
FLASH_NUM_ERROR_CODES	= 28,
FLASH_ERR_FLASH_WRITE	= 29,
FLASH_ERR_FLASH_VERIFY	= 30,
FLASH_ERR_FILE_OVERSIZE	= 31,
FLASH_ERR_FILE_EMPTY	= 32,
FLASH_UNKNOWN_FILE_TYPE	= 33,
FLASH_ERR_INVALID_DAC	= 34,
FLASH_ERR_FILE_CKSUM	= 35,
FLASH_FILE_SIZE_INCORRECT	= 36,
SWEEP_SPEED_TOO_FAST	= 37,
TRIGGER_TIMER_TOO_LARGE	= 38,
SWEEP_ALREADY_RUNNING	= 39,
SWEEP_ALREADY_STOPPED	= 40,
SERIAL_NUMBER_TOO_LARGE	= 41,
INVALID_PARK_COMMAND_SETTINGS	= 42,
INVALID_FLASH_SCAN_SETTINGS	= 43,
INVALID_FLASH_DAC_TABLE	= 44,
INVALID_FLASH_SERIAL_NUM	= 45,
SWEEP_UNDERRUN	= 46,
SWEEP_UNDERFLOW	= 47,
SWEEP_DMA_ERROR	= 48,
SWEEP_ON_OFF_TOO_CLOSE	= 49,
CAMERALINK_FPGA_PARAM_COUNT_MISMATCH	= 50,
INVALID_FLASH_FPGA_IMAGE	= 51,
INVALID_FPGA_SETTINGS	= 52,
FPGA_IMAGE_WRONG_SIZE	= 53,
FPGA_PROGRAM_TIMEOUT	= 54,
INVALID_COMMAND_FOR_THIS_BOARD_TYPE	= 55,
COMM_TIMEOUT	= 56,
RS232_BUFFER_ERROR	= 57,
RS232_EXIT_FROM_WAIT_FOR_COMMAND	= 58,
RS232_DATA_COUNT_MISMATCH_ERROR	= 59,
RS232_DEVICE_NOT_ATTACHED	= 60,
USB_BUFFER_SIZE_ERROR	= 61,
ETHERNET_INIT_ERROR	= 62,
ETHERNET_READ_ERROR	= 63,
ETHERNET_WRITE_ERROR	= 64,
ETHERNET_DISCONNECT	= 65,
COMMAND_ID_INVALID	= 66,
HANDPIECE_PARAM_COUNT_MISMATCH	= 67,
DAQ_PARAM_COUNT_MISMATCH	= 68,
INVALID_HANDPIECE_SETTINGS	= 69,
INVALID_DAQ_SETTINGS	= 70,
STEPPER_LIMIT_SWITCH_ACTIVATED	= 71,
STEPPER_HOME_SWITCH_ACTIVATED	= 72,
DAQ_FPGA_PROGRAM_TIMEOUT	= 73,
BAD_FPGA_PROGRAM_IN_FLASH	= 74,
NO_RESPONSE_FROM_FPGA_REG_READ	= 75,
SYNC_PACKET_ERROR_FROM_HOST	= 76,
DAQ_IMAGE_TOO_LARGE	= 77,
STEPPER_TABLE_TOO_LARGE	= 78,
INVALID_SPIN_SPEED	= 79,

## OCT Control Interface Specification

COMM_PORT_NOT_SUPPORTED	= 80,
INVALID_PULLBACK_PARAMETERS	= 81,
TOO_MUCH_FPGA_DATA	= 82,
STEPPER_NEVER_REACHED_HOME	= 83,
NVRAM_CRC_ERROR	= 84,
NO_DATA_IN_NVRAM	= 85,
SPIN_MOTOR_NOT_READY	= 86,
TOO_MANY_FRAMES_TO_RECORD	= 87,
TIMEOUT_WAITING_FOR_FPGA_RECORD_COMPLETE	= 88,
REGISTER_READ_RANGE_TOO_LARGE	= 89,
CANNOT_TURN_ON_SOURCE_CURRENT	= 90,
ERROR_SETTING_FPGA_RECORD_BIT	= 91,
FPGA_ERROR_VCCAUX_OUT_OF_RANGE	= 92,
FPGA_ERROR_VCCINT_OUT_OF_RANGE	= 93,
FPGA_ERROR_OVER_TEMP	= 94,
FPGA_ERROR_USER_OVER_TEMP	= 95,
FPGA_ERROR_TCD_TOO_SHORT	= 96,
FPGA_ERROR_TDC_TOO_LONG	= 97,
FPGA_ERROR_SWEEP_TRIGGER_OUT_OF_RANGE	= 98,
FPGA_ERROR_ADC_SAMPLE_CLOCK_NOT_DETECTED	= 99,
FPGA_ERROR_JPEG_CORE_ERROR	= 100,
FPGA_ERROR_FIFO_ERROR	= 101,
FPGA_ERROR_A_SCAN_PADDER_DROPPED_FRAME	= 102,
FPGA_CONFIG_TABLE_TOO_LARGE	= 103,
USB_CMD_HDR_CHKSUM_ERROR	= 104,
ETH_CMD_HDR_CHKSUM_ERROR	= 105,
RS232_1_CMD_HDR_CHKSUM_ERROR	= 106,
RS232_2_CMD_HDR_CHKSUM_ERROR	= 107,
PACKET_CHKSUM_ERROR	= 108,
PACKET_TOO_LARGE	= 109,
INTER_BRD_PACKET_CHKSUM_ERROR	= 110,
INTER_BRD_PACKET_TOO_LARGE	= 111,
INTER_BRD_RS232_1_CMD_HDR_CHKSUM_ERROR	= 112,
INTER_BRD_RS232_2_CMD_HDR_CHKSUM_ERROR	= 113,
COMM_TIMEOUT_AT_PASS_THROUGH	= 114,
LAST_RESET_WAS_WD_ERROR	= 115,
LAST_RESET_WAS_SWRST_ERROR	= 116,
LAST_RESET_WAS_DF_ERROR	= 117,
USB_INIT_FAILURE	= 118,
ENGINE_NOT_CONNECTED	= 119,
INTERBOARD_COMM_ERROR	= 120,
MOTOR_MOVE_OUT_OF_RANGE	= 121,
SOME_SETTINGS_WERE_UPDATED	= 122,
COMMAND_TO_GO_TO_ERROR_STATE	= 123,
INVALID_BOARD_CONFIG	= 124,
DAC_TABLE_NUM_TOO_LARGE	= 125,
CANNOT_START_SWEEP_TEC_IS_IN_ERROR	= 126,
PARK_VALUE_FILTER_1_OUT_OF_RANGE	= 127,
PARK_VALUE_FILTER_2_OUT_OF_RANGE	= 128,
PART_NUMBER_TOO_LARGE	= 129,
SOURCE_CURRENT_ON_OFF_NOT_ALLOWED	= 130,
INVALID_FPGA_CONFIG_TABLE	= 131,
CANNOT_START_SWEEP_INTERLOCK_ACTIVE	= 132,
CANNOT_TURN_ON_SOURCE_CURRENT_INTERLOCK_ACTIVE	= 133,
FPGA_PHY_STARTUP_TRIES	= 134,
BIT_VALUE_TOO_LARGE	= 135,
VALUE_MUST_BE_0_OR_1	= 136,
UDP_PACKETS_RECEIVED	= 137,
INVALID_CONFIGURATION_PARAMETERS	= 138,
SERIAL_NUMBER_CAN_ONLY_BE_SET_IN_CONFIGURATION_1	= 139,
CONFIGURATION_NOT_SETUP	= 140,

## OCT Control Interface Specification

MODEL_NUMBER_TOO_LARGE	= 141,
VOLTAGE_IS_OUT_OF_RANGE	= 142,
POWER_MONITOR_ERROR	= 143,
V33_ERROR	= 144,
VM5_ERROR	= 145,
V5_ERROR	= 146,
V15_ERROR	= 147,
V180_ERROR	= 148,
SYSTEM_IS_IN_ERROR	= 149,
ENGINE_BOARD_TEMP_OUT_OF_RANGE	= 150,
DAQ_BOARD_TEMP_OUT_OF_RANGE	= 151,
CANNOT_START_SWEEP_SYSTEM_IS_IN_ERROR	= 152,

### DLL Error Codes:

ERROR_READING	= 1000;
ERROR_WRITING_1	= 1001;
NO_DEVICE_PRESENT	= 1002;
CHECKSUM_ERROR	= 1003;
TOO_MANY_PACKET_TRIES	= 1004;
INTERNAL_DATA_ERROR	= 1005;
SCAN_SETTINGS_ARE_EMPTY	= 1006;
ERROR_READING_SCAN_SETTINGS	= 1007;
ERROR_WRITING_SCAN_SETTINGS	= 1008;
ERROR_SAVING_DAC_FILE	= 1009;
ERROR_READING_DAC_FILE	= 1010;
ERROR_WRITING_FPGA_SETTINGS	= 1011;
ERROR_READING_FPGA_SETTINGS	= 1012;
ERROR_WRITING_DAQ_SETTINGS	= 1013;
ERROR_READING_DAQ_SETTINGS	= 1014;
ERROR_WRITING_HANDPIECE_SETTINGS	= 1015;
ERROR_READING_HANDPIECE_SETTINGS	= 1016;
FPGA_SETTINGS_ARE_EMPTY	= 1017;
DAQ_SETTINGS_ARE_EMPTY	= 1018;
HANDPIECE_SETTINGS_ARE_EMPTY	= 1019;
TCP_READ_ERROR	= 1020;
TCP_WRITE_ERROR	= 1021;
TCP_CONNECT_ERROR	= 1022;
TCP_EVENT_SOCKET_ERROR	= 1023;
ERROR_CONNECTING_TO_DEVICE_FOR_HEARTBEAT	= 1024;
ERROR_READING_RS232	= 1025;
BOARD_DOES_NOT_SUPPORT_THIS_COMMAND	= 1026;
ERROR_READING_FPGA_DATA_FILE	= 1027;
ERROR_STRUCTURE_SIZE_DOES_NOT_MATCH	= 1028;
ERROR_DATA_SIZE_TOO_BIG	= 1029;
ERROR_FIRMWARE_IS_EMPTY	= 1030;
ERROR_USB_WRITE_INIT	= 1031;
ERROR_USB_READ_INIT	= 1032;
ERROR_USB_INIT	= 1033;
USB_READ_LEVEL_1_TIMEOUT	= 1034;
USB_READ_LEVEL_2_TIMEOUT	= 1035;
USB_DEVICE_CLOSED	= 1036;
USB_READ_READFILE_ERROR	= 1037;
USB_COMM_ERROR	= 1038;
MUTEX_TIMEOUT	= 1039;
DEVICE_CONNECTING	= 1040;
DEVICE_REBOOTING	= 1041;
HARD_ERROR	= 1042;

## OCT Control Interface Specification

ERROR_WRITING_2	= 1043;
ERROR_WRITING_3	= 1044;
ERROR_WRITING_4	= 1045;
ERROR_WRITING_5	= 1046;
NETWORK_THREAD_ALREADY_RUNNING	= 1047;
DAC_TABLE_NOT_LOADED	= 1048;